




6000 Series Showerhead




Installation Instructions



INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

6000 SERIES SHOWERHEAD

Fig.1



This instruction book covers the operation and cleaning of the showerhead.

Your showerhead has five showering patterns, with either a rub clean or kwik kleen faceplate.

ADJUSTING THE SHOWERHEAD

Five showerhead patterns are available (**fig.1**).

Adjust the spray pattern by turning the bezel on the showerhead in either direction until the desired pattern is obtained. A distinctive click will be heard once the lever has reached each of the five settings (**fig.2**).

6000 SERIES SHOWERHEAD

CLEANING

Triton recommends that all products are cleaned using warm, soapy water.


Do not use abrasive or aggressive chemical cleaning products as this may affect the product surface and finish and invalidate your guarantee.

Note: The showerhead can be cleaned quickly by simply rubbing your fingers over the faceplate.

Before cleaning, turn off the unit at the mains supply to avoid the shower being accidentally switched on.

IT IS IMPORTANT TO KEEP THE SHOWERHEAD CLEAN TO MAINTAIN THE PERFORMANCE OF THE SHOWER. The hardness of the water will determine the frequency of cleaning. For example, if the shower is used every day in a very hard water area, it may be necessary to clean the showerhead on a weekly basis.

Note: The shower head is not designed to be disassembled.



SPARE PARTS

Ref. Description **Part number**

1. 5 mode rub clean electric showerhead

white	88500014
chrome	88500015
Satin	88500018

5 mode mixer showerhead

white	88500016
chrome	88500017

2. 5 mode kwik kleen electric showerhead

white	88500011
chrome	88500012
satin	88500013

